



RAM AIR GEAR DRYERS ASSEMBLY INSTRUCTIONS

MODELS T4-MU, T4-HMU, T6-MU AND T6-HMU



TOOLS NEEDED FOR ASSEMBLY:

9/16" SOCKET



9/16" WRENCH



STEP ONE

Remove all bolts from deck.



STEP TWO

Install left vertical pipe with opening for motor facing away from center. Tighten bolts.



STEP THREE

Install right vertical accessory pipe aligning straight edge with edge of base. Tighten bolts.



STEP FOUR

Thread the outside stickmen on the horizontal top pipe. Be careful not to cross thread.



STEP FIVE

Install horizontal pipe with valves facing the front.



STEP SIX

Apply aluminum sealing tape on pipe joints.



STEP SEVEN

Attach stainless steel clamps with bolt head facing the front.



STEP EIGHT

Attach remaining stickmen. Be careful not to cross thread.



STEP NINE

Attach the blower to the vertical pipe. Adjust clamp as needed.



STEP TEN

Thread all accessory valves onto right accessory pipe.



QUESTIONS? CONTACT US.

855-393-3379 (USA) | 888-393-3379 (Canada)

www.ramairgeardryer.com

